

WB Aqua Fix Multipurpose Floor And Wall Adhesive



Features / Benefits

- Single component, just add water
- High strength, polymer modified
- Economical & Easy to use
- Bonds to various substrates
- Exceeds IS 15477:2019 – Type 3 TS1 Adhesive standards.
- Water and shock resistant.

Application

Designed especially for interior and exterior floor and wall installations of all types of ceramic tile, vitreous, semi-vitreous tile, glass mosaic tiles, precast terrazzo and natural stones over concrete and on a variety of substrates. Good underwater shear bond allows this product to be used for wet areas like swimming pools, sauna, water bodies and washrooms. Can be used for tile-on-tile applications and also as slurry bond adhesive in wet-on-wet applications

Multipurpose highly polymer modified adhesive for fixing large format tiles and stones on interior and exterior floor & wall.

Substrates

- Concrete & Concrete Masonry
- MIVON Concrete, VDF, Tremix Concrete
- Cement Mortar Beds
- Cement Plaster
- Ceramic tile, Vitrified Tile and Natural Stone
- Glass mosaic tile
- Brick Masonry
- Cement Backer Board**
- Cement Terrazzo
- Calcium Silicate Board**
- Gypsum Wallboard**

**Consult the backer board manufacturer's data sheet for the specific recommendations and load bearing capacity of specific board intended for use.

TECHNICAL DATA

Performance Properties:

Wall Berry Aqua Fix multipurpose floor and wall adhesive mixed with Water

Applicable Standards:

ANSI A118.4; EN 12004 & ISO 13007; IS15477:2019

ANSI Data		
Property: Test method	Requirement	Typical Values
Open Time (30 Minutes at 28 days): ANSI A118.4 Clause – 5.3	≥75 psi (0.50 Mpa)	130 psi – 150 psi (0.89 – 1.03 Mpa)
Sag: ANSI A118.4- Clause 6.0	≤0.02 Inches (0.50 mm)	0.008 – 0.012 Inches (0.20-0.30 mm)
Glazed wall tile Shear Strength		
7 Days: ANSI A118.4 – Clause 7.1.2	>300psi (2.07Mpa)	350-375 psi (2.40 Mpa-2.57 Mpa)
7 Days Water immersion: ANSI A118.4- Clause 7.1.3)	>200psi (1.38Mpa)	250-275 psi (1.72 Mpa-1.89 Mpa)
Porcelain Mosaic Tile Shear Strength		
1 Day: ANSI A118.4 – Clause 7.2.2	>75psi (0.50Mpa)	125 - 175 psi (0.86 – 1.20 Mpa)
7 Days: ANSI A118.4 – Clause 7.2.3	>200psi (1.38Mpa)	275 - 325 psi (1.89 – 2.23 Mpa)
7 Days Water immersion: ANSI A118.4 – Clause 7.2.4	>150psi (1.03Mpa)	225 - 275 psi (1.55 – 1.89 Mpa)
28 Days: ANSI A118.4 – Clause 7.2.5	>200psi (1.38Mpa)	300 - 350 psi (2.06 – 2.40 Mpa)
28 Days : W/ Freeze-Thaw cycling. ANSI A118.4 – Clause 7.2.5	>175psi (1.20Mpa)	275 - 325 psi (1.89 – 2.23 Mpa)
12 Weeks: ANSI A118.4 – Clause 7.2.7	>200psi (1.38Mpa)	300 - 350 psi (2.06 – 2.40 Mpa)
Quarry Tile Shear Strength		
28 Days : ANSI A118.4 – Clause 7.3.2	>150psi (1.03Mpa)	250 - 300 psi (1.72 – 2.06 Mpa)
28 Days : W/ Freeze-Thaw cycling. ANSI A118.4 – Clause 7.3.3	>100psi (0.69Mpa)	200 - 250 psi (1.37 – 1.72 Mpa)

The adhesive mortar conforms to ANSI A118.4ET

EN / ISO Data

Property: Test Method	Requirement	Typical Values
Open Time: EN 1346	≥0.50 N/mm ²	0.85 – 1.10 N/mm ²
Slip Resistance: EN 1308	≤0.50 mm	0.20 - 0.30 mm
Tensile Adhesion Strength		
Initial: EN 1348 – Clause 8.2	≥1.00 N/mm ²	1.50 – 2.00 N/mm ²
After Water Immersion: EN 1348 - Clause 8.3	≥1.00 N/mm ²	1.50 – 1.75 N/mm ²
Heat Ageing: EN 1348 – Clause 8.4	≥1.00 N/mm ²	1.15 – 1.40 N/mm ²
Freeze- Thaw: EN 1348 – Clause 8.5	≥1.00 N/mm ²	1.75 – 2.00 N/mm ²
Transverse Deformation: EN12002	≥2.5mm <5.00mm	2.55 mm - 2.65 mm

The adhesive mortar conforms to EN12004 / ISO 13007 as C2TES1

IS Data		
Property: Test method	Requirement	Typical Values
Tensile Adhesion		
Dry Condition – Annex A (Clause 5.1)	Minimum 1.5 N/mm ²	1.70-1.80 N/mm ²
Wet Condition – Annex A (Clause 5.1)	Minimum 1.0 N/mm ²	1.50-1.60 N/mm ²
Shear Adhesion		
Dry Condition – Annex B (Clause 5.2)	Minimum 1.5 N/mm ²	1.80-1.90 N/mm ²
Heat Ageing – Annex B (Clause 5.2)	Minimum 1.0 N/mm ²	1.20-1.30 N/mm ²
Wet Conditions – Annex B (Clause 5.2)	Minimum 1.0 N/mm ²	1.30-1.40 N/mm ²
Slip Resistance		
Slip Resistance – Annex E (Clause 5.5)	≤0.5 mm	0.3-0.4 mm
Transverse Deformation		
Transverse Deformation: (Clause 5.6)	≥2.5mm <5.00mm	2.55 mm - 2.65 mm

The Adhesive mortar conforms to IS 15477: 2019 - Type 3 T S1 Adhesive

Packaging:

30 kg bags

Colour:

Grey and white

Coverage:

Approx 85-90 sft per 30kg bag with 1/4" x 1/4" (6mm x

6mm) square notched trowel for average bed of 3mm.

Coverage will vary depending on trowel notch size, type and size of tile and substrate smoothness and evenness.

Working Properties at 70° F (21° C)

WB Aqua Fix Multipurpose Adhesive mixed with Water

Open Time	30 minutes
Adjustability Time	30 minutes
Pot Life	4 hours
Time to Heavy Traffic	16 - 24 hours

Specifications subject to change without notification.
Results shown are typical but reflect test procedures used.
Actual field performance will depend on installation methods and site conditions.

INSTALLATION

Surface Preparation:

All surfaces should be between 40° F(4°C) and 104° F(40°C) and structurally sound, clean and free of all dirt, oil, grease, loose peeling paint, laitance, concrete sealers or curing compounds.

Check the surface to be true to plumb. All slabs must be plumb and true to within 1/4" (6mm) in 10 ft(3m). Rough or uneven concrete surfaces should be made smooth with WALL BERRY ^{Screed}/Plaster material to provide a wood float (or better) finish.

Dry, dusty concrete slabs or masonry should be dampened and excess water swept off. Installation may be made on a damp surface. New concrete slabs shall be damp cured and 28* days old before application.

*No minimum cure time for concrete slabs when thin-set mortar is mixed with SBR LATEX additive.

Expansion joints shall be provided through the tile work from all construction or expansion joints in the substrate.

Do not cover expansion joints with adhesive mortar.

Expansion joints to be filled with expansion joint sealant for the better results

NOTES: For tile or stone installations on plywood and wood substrates, Premium adhesive or water seal adhesive is recommended. Please refer specific product Technical Data Sheet for detailed recommendations.

For all stone with a back protection mesh, it is important to remove the mesh first and also remove the epoxy layer by light grinding to ensure perfect bond with the adhesive.

Mixing:

Place clean, potable water into a clean mixing bowl. Add WB Aqua fix powder into the mixing bowl. Use approximately

Grey - 8.5 - 9L of water for 30 kg of powder

White- 9.0-9.5 L of water for 30 kg of powder.

Mix by hand or with a slow speed mixer to a smooth, trowel able consistency. Allow adhesive to slake for 5-10 minutes. Adjust consistency if necessary. Remix and apply with the proper sized notched trowel.

Note: Addition of "Tile Bond", partially or completely replacing water would enhance the bond strength, flexibility of the thin-set mortar.

* Contact Wall Berry technical services for large format tile or stone installations on exterior surfaces.

APPLICATION:

a) Tile/Stone

Apply adhesive to the substrate with the flat side of the trowel, pressing firmly to work into surface. Comb on additional adhesive with the notched side. Use the proper sized notched trowel to ensure full bedding of the tile. Spread as much adhesive as can be covered with tile in 10 minutes. Back butter large format tiles (> 12"x12") to provide full bedding and firm support. Place tiles into wet, sticky adhesive and beat in using a beating block and rubber mallet to imbed tile and adjust level. Check adhesive for complete coverage by periodically removing

a tile and inspecting bedding adhesive transfer onto back of tile. Use of Wall Berry spacers is recommended to provide grout joints between tiles / stones. The joint width shall be as per the recommendation of architect / engineer. Remove the spacers when the adhesive is set firm.

If adhesive is skinned over (not sticky), remove and replace with fresh adhesive.

For highly absorbent natural stones which may form a wet patch when adhesive is used, it is recommended to use suitable Wall Berry Impregnating sealer on all sides. Wall Berry primer admix can also be used as a bottom coat for natural stones to prevent wet patches during installation. Please refer Technical Data Sheets of product intended for use for specific instructions of use

b) Glass Mosaic tiles: (Paper Face mounted)

The WB Aqua fix adhesive shall be applied to the surface to be tiled with a notched trowel using a scraping motion to work the adhesive into good contact with the surface to be covered. Notch trowel with notches approximately 4mm is recommended to get a bed thickness of 1.5-2mm. V-notch of 3mm also can be used to get bed thickness of 1.5mm. Apply only so much that can be covered with tile within 10-15 minutes or while the adhesive surface is still tacky. The Glass Mosaic tiles shall then be set in place and beaten gently with mallet or grouting float to insure 100% full bedding. Tiles shall be aligned to achieve uniform joints and then allowed to set until firm. Excess adhesive must be cleaned from the surface of the tile with a wet cloth or sponge while the adhesive is fresh and has not hardened.

After the tiles are set firm, the face of the sheets of front mounted glass mosaic tiles shall then be dampened and the face mount paper can be removed.

For Glass mosaic tiles which are mesh backed, use resin-based adhesive for installation. The cement based adhesives are not compatible with resin backed (mesh backed) tiles.

While installing tile/stone on the external walls and floors, we need to provide the joints by creating spaces between the tiles/stones and fill them up with WB Epoxy grout. (In the absence of spacer joints, the surface movements can push tiles/stones away from the substrate causing debonding of tiles or stones)

The exterior tile / stone installations are provided with joints (spaces) on the periphery of the area without allowing the tile / stone to be bound by the peripheral masonry work or plaster.

HOT & COLD WEATHER TILING:

* Please refer technical document on Hot & Cold weather tiling

Grouting:

Grout installation shall be commenced after a minimum of 24 hours curing time at 70°F (21° C). Grout with Wall Berry Epoxy Grout For maximum stain resistance of Internal spacer joints applications. For maximum stain resistance of External spacer joints applications use Wall Berry Epoxy grout which can accommodate movements and is UV resistant.

CUSTOMER CARE

ECO GREEN TECH CONSTRUCTION CHEMICALS.

Survey No 63/4, Begur village, Begur Hobli,
Bangalore South Taluk 560068

Tel: +919108265652, +919663143954

Customer Care : info@ecogreentechcc.in

Website: www.ecogreentechcc.in

NOTE TO THE SPECIFIER AND INSTALLER: